

PORTAVALIGIE LATERALE SPECIFICO - SPECIFIC TUBULAR SIDE-CASE HOLDER
 PORTE-VALISES LATÉRAUX SPÉCIFIQUE - SPEZIFISCHES STAHLROHR-SEITENTRÄGER
 PORTA-EQUIPAJE LATERAL ESPECIFICO

BMW F650GS 00/04

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS
 INSTRUCCIONES DE MONTAJE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

ATTENZIONE - WARNING - ATTENTION

IL SUPPORTO "A" VA INSERITO TRA IL FIANCHETTO ED IL SILENZIATORE.

THE UPPER SUPPORT "A" MUST BE INSERTED BETWEEN SIDE PANEL AND THE SILENCER

LE SUPPORT "A" DOIT ETRE INSERE' ENTRE LE COTE PLASTIQUE ET LE POT.

1

 PORTAVALIGIE
 SIDE SUPPORT
 SUPPORT LATERAL
Q.TY n°2 (dx-sx)

2

 PONTE POSTERIORE
 REAR BRIDGE
 PONT POSTERIEURE
Q.TY n°1

3

 VITE TBEI M8 X 20
 SCREW M8 X 20
 VIS M8 X 20
Q.TY n°2

4

 VITE TBEI M6 X 16
 SCREW M6 X 16
 VIS M6 X 16
Q.TY n°2

5

 VITE TE M8 X 35
 SCREW M8 X 35
 VIS M8 X 35
Q.TY n°2

6

 FISHER 23,5X 25
 foro Ø 8,5
 FISHER
 FISHER
Q.TY n°2

7

 RONDELLA Ø 8
 WASHER Ø 8
 RONDELLE Ø 8
Q.TY n°2

8

 DISTANZIALE 14X3
 foro Ø 8,5
 COLLAR DISTANCE
 COLLIER DE SEPAR.
Q.TY n°2

9

 VITE TBEI M8 X 25
 SCREW M8 X 25
 VIS M8 X 25
Q.TY n°2

10

 RONDELLA ORIGINALE
 ORIGINAL WASHER
 RONDELLE ORIGINALE
Q.TY n°-

11

 RONDELLA Ø 6
 WASHER Ø 6
 RONDELLE Ø 6
Q.TY n°4

