

PIASTRA SPECIFICA - SPECIFIC PLATE
PLATINE SPECIFIQUE - SPEZIFISCHE PLATTE - PLETINA ESPECÍFICA

BMW K100 1990

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS
INSTRUCTIONS DE MONTAGE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

N°	DESCRIZIONE DEL KIT (KIT DESCRIPTION) (DESCRIPTION DU KIT)	QUANTITA' (QUANTITY) (QUANTITE')
1	PIASTA E 250 (PLATE E 250) (PLAQUE E 250)	1
2	PIASTRINA (LITTLE PLATE) (PETITE PLAQUE)	4
3	RONDELLA Ø 6 (WASHER Ø 6) (RONDELLE Ø 6)	8
4	VITE TCEI M 6 X 20 (SCREW M 6 X 20) (VIS M 6 X 20 6 PANS CREUX)	4
5	PORTAPACCHINO (LUGGAGE RACK) (PORT PAQUETS)	1
6	DADO M 6 (NUT M 6) (ECROU M 6)	4
7	RONDELLA IN GOMMA FORO Ø6 (RUBBER WASHER) (RONDELLE EN CHAOUTCHOUC)	4
8	RONDELLA Ø 6 X 18 (WASHER Ø 6 X 18) (RONDELLE Ø 6 X 18)	4
9	VITE TE M 6 X 20 (SCREW M 6 X 20) (VIS M 6 X 20)	2
10	VITE TE M 6 X 25 (SCREW M 6 X 25) (VIS M 6 X 25)	2

**FISSATA LA PIASTRA
MONTARE IL COPRIPIASTRA IN
DOTAZIONE.**

**AFTER YOU HAVE FIXED THE PLATE
MOUNT THE COVERPLATE PROVIDED.**

**APRES QUE VOUS AVEZ MONTE LA
PLATINE MONTER LE COUVRE PLATINE
EN DOTATION.**

