





# USER INFORMATION SHEET

## LIDLOCK

1. Make sure the digits line up with the red arrow and show the number sequence \*0000\*
2. Twist the red arrow from the hinge until you hear a click and it doesn't move any further.



3. Change the code to your memorable 4 digit code of choice.
4. Twist the red arrow back into the "Set" position to save your desired code.



**FR** Pour télécharger ces instructions dans votre langue, veuillez consulter le site:

**DE** Diese Anleitung können Sie in Ihrer Sprache unter folgendem Link herunterladen:

**ES** Para descargar estas instrucciones en su idioma, visite:

**IT** Per scaricare queste istruzioni nella lingua d'interesse, visitare:

**PL** Aby pobrać poniższe instrukcje w twoim języku prosimy odwiedzić stronę:

**JP** あなたの言語の説明書をダウンロードするには、以下のウェブサイトをご覧ください:

[https://www.oxfordproducts.com/motorcycle/downloads/guidance\\_and\\_instructions/](https://www.oxfordproducts.com/motorcycle/downloads/guidance_and_instructions/)

---

# WARNING

---



**Do not use for climbing**



**Not suitable for children under 36 months**

**OXFORD**

Essential Rider Equipment

Oxford Products Ltd

Witney, Oxon, OX29 0YA

[www.oxfordproducts.com](http://www.oxfordproducts.com)

 [/oxfordproductsltd](https://www.facebook.com/oxfordproductsltd)

 [/oxfordproductsltd](https://www.youtube.com/oxfordproductsltd)

 [@oxfordproducts](https://twitter.com/oxfordproducts)